


# Instructions for Setting the Combination

Set your own combination in seconds without special tools or disassembly.

With 1,000 combinations to choose from you can be confident in the security of your keys. Change the combination any time!



## Easy Instructions: Setting the Combination

Select the 3 digit code you will use before starting to set the code on your Combi-Cam.

1. Begin with the dials set to the current opening code. From the factory the Combi-Cam is set to 0-0-0.
2. Locate the code reset button along the outside edge of the Combi-Cam.
3. Depress the code reset button using a pen, safety pin or paper clip.
4. Maintain pressure on the code reset button for the remainder of the resetting process.
5. Turn the dials to your intended combination.
6. Release pressure on the reset button. The combination is now set to your desired combination. It may be helpful to write down the combination and keep it in a secure place.

## Restrict Access to the Code Reset Button (Optional)

You can quickly convert the Combi-Cam so only you can access the code reset button. To do so, take off the screw and stop cam at the back end of the lock cylinder. Remove the lock, and then reinstall it so the numbers are upside down. Rotate the lock 180 degrees (a 1/2 turn). Replace the stop-cam and screw in their original orientations. The code reset button is now concealed.