






Right Hand Default Setting

vs. Left Hand




Peg on stop cam is on the right side



www.combi-cam.com

Peg on stop cam is on the left side



Knob rotates to the right to open lock

Knob rotates to the left to open lock